


MODEL: HPJB-SERIES

- Rail Bearing Puller / Installer
- Capacity : 100 Ton
- Maximum working pressure : 10,000 psi / 700 Bar

FEATURES

- Designed for easy dismantling and installing of Rail axle bearings
- Simple, efficient and easy operation providing pulling force up to 100 ton
- Portable unit for easy manoeuvring and storage

SPECIFICATIONS

Model	Stroke (mm)	Capacity (Ton) Pull / Install	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (mm)	Weight (kg)	Pump
HPJB100-220	392	100 / 68	652	370	1047	900	1940-2209	1530	775	PED065
HPJB100-380	392	100 / 68	652	370	1047	900	1940-2209	1530	805	PED180
HPSJB100-220	254	100 / 68	627	384	731	909	1299	1175	370	PED065
HPSJB100-380	254	100 / 68	627	384	731	909	1299	1175	410	PED180

Imperial Accessories	Class B 108 x 203	Class C 127 x 229	Class D 140 x 254	Class E 152 x 279	Class EE 140 axle	Class EE 152 axle	Class F 165 x 305	Class G 178 x 305	Class G 165 axle	Class GG 165 axle
Pulling Shoe	1B11916 - Included as part of basic machine							1B11917	1B11917	1B11917
Pulling shoe insert adaptor	1B11914	1B11911	1B11912	1B11913	1B11913	1B11915	1B11915	-	-	-
Guide tube & cap screw assembly	1B11908	1B11902	1B11900	1B11901	1B11902	1B11903	1B11904	1B11906	1B11905	1B11905
Cap Screw **	1B11920	1B11921	1B11922	1B11923	1B11924	1B11922	1B11925	1B11925	1B11926	1B11926
Guide tube adaptor	1B11882	1B11881	1B11881	1B11883	1B11883	1B11883	1B11883	1B11883	1B11883	1B11883
Guide tube	1B11894 - Included as part of basic machine							1B11895	1B11895	1B11895
Installing tube adaptor ring	1B11880	1B11888	1B11889	1B11890	1B11890	1B11891	1B11891	1B11893	1B11892	1B11892

Metric Accessories	120	130	140	150
Pulling shoe insert adaptor	1B11910	1B11911	1B11912	1B11913
Guide tube & cap screw assembly	1B11896	1B11897	1B11898	1B11899
Cap Screw **	1B11918	1B11918	1B11918	1B11919
Guide tube adaptor	1B11883	1B11883	1B11883	1B11883
Installing tube adaptor ring	1B11884	1B11885	1B11886	1B11887

** Screws are supplied with the guide tube and should be ordered as replacements only

